


Installation & Test Guide


For HP LaserJets & MFPs with 100 Pin DIMM

Extending the Resources and Abilities of Your Printer




1

Use the power switch to turn off the printer and then unplug the power cord from the printer.



2

Unplug all remaining cables and cords from the printer.





3

Carefully open the DIMM access door located on the left side of the printer.


4

Remove the DIMM from the anti-static bag it came in, grasping the DIMM along the top edge away from the gold contacts.




5

The DIMM has a notch cut in the edge between some of the gold contacts. Orient the DIMM so this notch aligns with the bump in the printer's connector and insert the DIMM into the connector.



6

Press the DIMM body in until the metal retaining pins click.



7

Close the DIMM access door, reconnect all cables and cords, then turn the power switch on.

Congratulations!

You are now ready to store resources on your LaserJet Flash Memory. To test your LaserJet Flash Memory, simply use your printer's control panel to print a File Directory. The File Directory is different than the PCL Font List. On most printer models, select "Information" and then "File Directory".

See the reverse side of this sheet for an example of the first page of a File Directory showing the LaserJet Flash Memory. The File Directory may vary a little between different printer models. If the File Directory shows that a storage device was found, then the printer has found your LaserJet Flash Memory.

TypeHaus Reorder Part Number: 11B702-02

Solutions
Business Partner



TypeHaus, Inc.
655 Second Street
Encinitas, CA 92024
760.334.3555
www.typehaus.com

© 2010 TypeHaus, Inc. All rights reserved. (2358-100612A)

HP LaserJet Printers

File Directory Page



Storage Information

Device Type: USB STORAGE
 Device Location: USB STORAGE 1
 Device Capacity: 955 MB
 Free Space: 948 MB
 Write Protect: DISABLED
 Hard Drive Encryption Status:
 Not applicable

Permissions	Owner	File Size	Directory/File Name
drwxrwxrwx	0	Directory	0:
drwxrwxrwx	0	Directory	0:\PostScript
drwxrwxrwx	0	Directory	0:\PJL
drwxrwxrwx	7	Directory	0:\webServer
-rw-rw-r--	7	205	.java_login.config
drwxrwxrwx	7	Directory	0:\webServer\config
-rw-rw-r--	7	22062	soe.xml
-r-xr-xr-x	7	45	version.6
drwxrwxrwx	7	Directory	0:\webServer\home
-r-xr-xr-x	7	171	device.html
-r-xr-xr-x	7	219	hostmanifest
drwxrwxrwx	7	Directory	0:\webServer\home\JobCapabilities
-r-xr-xr-x	7	14330	JobCapabilitiesTicket.zip
drwxrwxrwx	7	Directory	0:\webServer\home\images
-r-xr-xr-x	7	68	transparent_pixel.gif
-r-xr-xr-x	7	54	tab_right.gif
-r-xr-xr-x	7	206	question.gif
-r-xr-xr-x	7	140	menus_vert_line.gif
-r-xr-xr-x	7	133	menus_plus_node.gif
-r-xr-xr-x	7	130	menus_minus_lastnode.gif
-r-xr-xr-x	7	129	menus_minus_node.gif
-r-xr-xr-x	7	125	menus_minus_lastnode.gif
-r-xr-xr-x	7	11281	masthead.jpg
-r-xr-xr-x	7	116	logwarning.jpg
-r-xr-xr-x	7	461	logo.gif
-r-xr-xr-x	7	106	loginfo.jpg
-r-xr-xr-x	7	268	hplogo_inline.gif
-r-xr-xr-x	7	1069	go_button2red.gif
-r-xr-xr-x	7	479	go_button2greencheck.gif
-r-xr-xr-x	7	1070	go_button2green.gif
-r-xr-xr-x	7	5258	chip_red.jpg
-r-xr-xr-x	7	79	binOK.gif
-r-xr-xr-x	7	91	binUNKNOWN.gif
-r-xr-xr-x	7	79	binFULL.gif
-r-xr-xr-x	7	74	binEMPTY.gif
-r-xr-xr-x	7	272	Yellow_Toner.gif
-r-xr-xr-x	7	401	Yellow_Image_Drum.gif
-r-xr-xr-x	7	270	Magenta_Toner.gif
-r-xr-xr-x	7	605	Magenta_Image_Drum.gif
-r-xr-xr-x	7	896	LevelUnknown.gif
-r-xr-xr-x	7	174	LevelEmpty.gif
-r-xr-xr-x	7	186	Level40-100.gif
-r-xr-xr-x	7	182	Level20-40.gif
-r-xr-xr-x	7	185	Level10-20.gif
-r-xr-xr-x	7	185	Level1-10.gif
-r-xr-xr-x	7	341	Image_Cleaning_Kit.gif
-r-xr-xr-x	7	261	Cyan_Toner.gif