


Installation & Test Guide


For HP LaserJets & MFPs with 144 Pin DIMM

Extending the Resources and Abilities of Your Printer




1

Use the power switch to turn off the printer and then unplug the power cord from the printer.



2

Unplug all remaining cables and cords from the printer.





3

Carefully open the DIMM access door located on the left side of the printer.


4

Remove the DIMM from the anti-static bag it came in, grasping the DIMM along the top edge away from the gold contacts.




5

The DIMM has a notch cut in the edge between some of the gold contacts. Orient the DIMM so this notch aligns with the bump in the printer's connector and insert the DIMM into the connector.



6

Press the DIMM body in until the metal retaining pins click.




7

Close the DIMM access door, reconnect all cables and cords, then turn the power switch on.

Congratulations!

You are now ready to print MICR using your printer. The CD that came with your MICR Font Solution contains an application for testing the new capabilities.



1. Insert the CD in your CD/DVD drive and use Windows File Explorer to browse the CD and double-click on DirectPrint.exe.
2. In the "Filename" section, click the "..." button. Browse to select the file "PCL5 Font List.prn" also located on the CD.
3. In the "Printer/IP" section, select the printer from the dropdown list or enter the IP address if it is attached to the network.
4. Select the "Print" button.
5. Compare the printed font list first page to the reverse side of these instructions. Some variation may exist for different printer models. The MICR font appears on a later page of the font list.
6. Select the "Exit" button to close the application.

TypeHaus Reorder Part Number: 11B583-D2

Solutions
Business Partner



TypeHaus, Inc.
655 Second Street
Encinitas, CA 92024
760.334.3555
www.typehaus.com

HP LaserJet

PCL Font List

1

ROM DIMM M1

Typeface	Pitch/Point	Escape sequence	Font #	Font ID
ABCDEFghijjĀ°čŇi Courier	Scale	<esc>(<input type="checkbox"/>)<esc>(s0p <input type="checkbox"/> h0s0b4099T	M1 0	
ABCDEFghijjĀ°čŇi CG Times	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v0s0b4101T	M1 1	
ABCDEFghijjĀ°čŇi CG Times	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v0s3b4101T	M1 2	
ABCDEFghijjĀ°čŇi CG Times	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v1s0b4101T	M1 3	
ABCDEFghijjĀ°čŇi CG Times	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v1s3b4101T	M1 4	
ABCDEFghijjĀ°čŇi CG Omega	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v0s0b4113T	M1 5	
ABCDEFghijjĀ°čŇi CG Omega	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v0s3b4113T	M1 6	
ABCDEFghijjĀ°čŇi CG Omega	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v1s0b4113T	M1 7	
ABCDEFghijjĀ°čŇi CG Omega	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v1s3b4113T	M1 8	
ABCDEFghijjĀ°čŇi Coronet	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v1s0b4116T	M1 9	
ABCDEFghijjĀ°čŇi Clarendon	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v4s3b4140T	M1 10	
ABCDEFghijjĀ°čŇi Univers	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v0s0b4148T	M1 11	
ABCDEFghijjĀ°čŇi Univers	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v0s3b4148T	M1 12	
ABCDEFghijjĀ°čŇi Univers	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v1s0b4148T	M1 13	
ABCDEFghijjĀ°čŇi Univers	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v1s3b4148T	M1 14	
ABCDEFghijjĀ°čŇi Univers	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v4s0b4148T	M1 15	
ABCDEFghijjĀ°čŇi Univers	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v4s3b4148T	M1 16	
ABCDEFghijjĀ°čŇi Univers	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v5s0b4148T	M1 17	
ABCDEFghijjĀ°čŇi Univers	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v5s3b4148T	M1 18	
ABCDEFghijjĀ°čŇi Antiquolive	Scale	<esc>(<input type="checkbox"/>)<esc>(s1p <input type="checkbox"/> v0s0b4168T	M1 19	

 Pitch Symbol set Point size